
instructions for receiving your la marzocco espresso machine.

follow this chart

Liability for the equipment transfers from the shipper to you at your signature.

delivery arrives

delivery receipt for your signature



206-706-9104 x 109

write "subject to inspection" on delivery receipt. if driver resists, explain that you are not the installer, and therefore not able to inspect.


no

Sign. Driver is free to leave.



if any of these occur, your machine may be damaged.

installer: follow these steps to inspect your machine.



is the shock sensor activated?



is the outside of the box damaged?

(corners crushed, holes in packaging?)



is the inside of the box damaged?



is the machine damaged?

