

linea classic preventative maintenance 12 month checklist



Customer: _____

Technician: _____

Date: _____

Machine Data

Serial Number: _____

Voltage: _____

Number of Groups: _____

PM kit / replacement parts:

1 group (LINEA.12.1)

3 group (LINEA.12.3)

2 group (LINEA.12.2)

4 group (LINEA.12.4)

Check/inspect:

filter baskets and springs condition

clean auto-fill probe

all buttons for proper operation

Wiring harness, power cord, cap and outlet

brewing pressure → _____ bar

expansion valve operation → _____

max pressure: _____ bar

all fittings and valves for leaks

Flow meter impellers _____ °f

Coffee boiler temperature → _____

Steam boiler pressure stat

water line, drain box, and drain hose for leaks or clogs

Steam boiler contactor

flow-rates for each group ml/30s →

G1: _____ g G2: _____ g G3: _____ g G4: _____ g

If AV Model

flow meter field resistance (2.2KΩ±10%) → _____

G1: _____ kΩ G2: _____ kΩ G3: _____ kΩ G4: _____ kΩ

Test DC voltage _____ VDC

If MP Model

Non conical MP valve rebuild (SA600/K2)

Notes:

Water Quality LM test kit (F.9.000.01)

filtration system manufacturer and type: _____

carbon filter

ion exchange/softener

WAC

reverse osmosis

other/none

value	Min	max	pre	post	value	min	max	pre	post
Total Hardness ppm	5	70			Free Chlorine ppm	0	0.05		
Alkalinity ppm	5	80			Total Chlorine ppm	0	0.1		
Chloride ppm	0	30			pH	6.5	8.5		
Iron ppm	0	0.02			Total Dissolved Solids ppm	10	150		

technician signature: _____

customer signature: _____