

strada s preventative maintenance 3/9 month checklist



Customer: _____

Technician: _____

Date: _____

Machine Data

Serial Number: _____

Voltage: _____

Number of Groups: _____

Replace:

- diffuser screens (F.3.040)
- group gaskets: 8mm (H.3.001) or 8mm silicon (H.3.007)

Check/inspect:

- filter baskets and springs condition
- drain box and hose for leaks or clogs
- all buttons for proper operation

brewing pressure _____ bar

expansion valve operation _____ max pressure: _____ bar

flow meter field resistance (2.2KΩ±10%) G1: _____ kΩ G2: _____ kΩ G3: _____ kΩ

steam valve operation

if ABR: run "scale test"

all fittings and valves for leaks

vacuum breakers for proper operation

flow-rates for each group ml/30s G1: _____ g G2: _____ g G3: _____ g

water sensor for leaks

water and drain lines

clean auto-fill probe

Power cord, cap and outlet

With integrated scales:

Confirm or calibrate scales with 100g weight

Notes:

Water Quality LM test kit (F.9.000.1)

filtration system manufacturer and type: _____

carbon filter ion exchange/softener WAC reverse osmosis other/none

value	Min	max	pre	post	value	min	max	pre	post
Total Hardness ppm	5	70			Free Chlorine ppm	0	0.05		
Alkalinity ppm	5	80			Total Chlorine ppm	0	0.1		
Chloride ppm	0	30			pH	6.5	8.5		
Iron ppm	0	0.02			Total Dissolved Solids ppm	10	150		

technician signature: _____ customer Signature: _____