

strada x preventative maintenance 3/9 month checklist



la marzocco
handmade in florence

Customer: _____

Technician: _____

Date: _____

Machine Data

Serial Number: _____

Voltage: _____

Number of Groups: _____

Replace:

- Diffuser screens (A.5.095)
- group gaskets and bumpers: (1207)

Check/inspect:

- filter baskets and springs condition
- jaw bushings
- all buttons for proper operation
- confirm auto flush system is functioning
- Straight-In piston for leaks under pressure

brewing pressure →

G1: G2: G3:

expansion valve operation → *max pressure:*

G1: G2: G3:

flow meter field resistance (2.2KΩ±10%) →

G1: G2: G3:

steam valve operation

clean auto-fill probe

all fittings and valves for leaks

drain box

vacuum breakers for proper operation

Power cord, cap and outlet

Water sensor for leaks

water and drain lines

flow-rates for each group ml/30s →

G1: G2: G3:

Confirm or calibrate scales with 100g weight

Notes:

Water Quality LM test kit (F.9.000.01)

filtration system manufacturer and type: _____

- carbon filter
 ion exchange/softener
 WAC
 reverse osmosis
 other/none

value	Min	max	pre	post	value	min	max	pre	post
Total Hardness ppm	5	70			Free Chlorine ppm	0	0.05		
Alkalinity ppm	5	80			Total Chlorine ppm	0	0.1		
Chloride ppm	0	30			pH	6.5	8.5		
Iron ppm	0	0.02			Total Dissolved Solids ppm	10	150		

technician signature: _____ customer Signature: _____