

linea classic preventative maintenance 6 month checklist



la marzocco
handmade in florence

Customer: _____

Technician: _____

Date: _____

Machine Data

Serial Number: _____

Voltage: _____

Number of Groups: _____

PM kit / replacement parts:

1 group (LINEA.6.1)

3 group (LINEA.6.3)

2 group (LINEA.6.2)

4 group (LINEA.6.4)

Check/inspect:

filter baskets and springs condition

all fittings and valves for leaks

all buttons for proper operation

vacuum breakers for proper operation

brewing pressure →

bar

expansion valve operation →

max pressure:

bar

Coffee boiler temperature →

°f

flow-rates for each group ml/30s →

G1: g G2: g G3: g G4: g

clean auto-fill probe

water line and water meter for leaks

drain box and hose for leaks or clogs

Power cord, cap and outlet

If AV Model

flow meter field resistance (2.2KΩ±10%) →

G1: kΩ G2: kΩ G3: kΩ G4: kΩ

If MP Model

Ensure MP Valve operation. →

Non conical MP Valve only, rebuild if necessary (SA600/K2)

Notes:

Water Quality LM test kit (F.9.000.01)

filtration system manufacturer and type: _____

carbon filter

ion exchange/softener

WAC

reverse osmosis

other/none

value	Min	max	pre	post	value	min	max	pre	post
Total Hardness ppm	5	70			Free Chlorine ppm	0	0.05		
Alkalinity ppm	5	80			Total Chlorine ppm	0	0.1		
Chloride ppm	0	30			pH	6.5	8.5		
Iron ppm	0	0.02			Total Dissolved Solids ppm	10	150		

technician signature: _____

customer Signature: _____