

strada s preventative maintenance 6 month checklist



la marzocco
handmade in florence

Customer: _____

Technician: _____

Date: _____

Machine Data

Serial Number: _____

Voltage: _____

Number of Groups: _____

PM kit / replacement parts:

2 group (STRADA.S.6.2)

3 group (STRADA.S.6.3)

Check/inspect:

filter baskets and springs condition

drain box and hose for leaks or clogs

all buttons for proper operation

brewing pressure

_____ bar

expansion valve operation

max pressure: _____

_____ bar

flow meter field resistance (2.2KΩ±10%)

G1: _____ kΩ G2: _____ kΩ G3: _____ kΩ

steam valve operation

if ABR: run "scale test"

all fittings and valves for leaks

vacuum breakers for proper operation

flow-rates for each group ml/30s

G1: _____ g G2: _____ g G3: _____ g

Water sensor for leaks

water and drain lines

clean auto-fill probe

Power cord, cap and outlet

With integrated scales:

Confirm or calibrate scales with 100g weight

Notes:

Water Quality LM test kit (F.9.000.01)

filtration system manufacturer and type: _____

carbon filter

ion exchange/softener

WAC

reverse osmosis

other/none

value	Min	max	pre	post	value	min	max	pre	post
Total Hardness ppm	5	70			Free Chlorine ppm	0	0.05		
Alkalinity ppm	5	80			Total Chlorine ppm	0	0.1		
Chloride ppm	0	30			pH	6.5	8.5		
Iron ppm	0	0.02			Total Dissolved Solids ppm	10	150		

technician signature: _____

customer Signature: _____