

strada x preventative maintenance 6 month checklist



la marzocco
handmade in florence

Customer: _____

Technician: _____

Date: _____

Machine Data

Serial Number: _____

Voltage: _____

Number of Groups: _____

Replace:

2 group (STRADA.X.6.2)

3 group (STRADA.X.6.3)

Check/inspect:

filter baskets and springs condition

portafilter jaw bushings

all buttons for proper operation

brewing pressure →

expansion valve operation → *max pressure:*

flow meter field resistance (2.2KΩ±10%) →

steam valve operation

confirm or calibrate scales with 100g weight

all fittings and valves for leaks

vacuum breakers for proper operation

flow-rates for each group in AV mode ml/30s →

confirm auto flush system is functioning

Straight-In piston for leaks under pressure

group cap micro switches

G1: G2: G3:

G1: G2: G3:

G1: G2: G3:

clean auto-fill probe

Water sensor for leaks

drain box/hose and water line for leaks or clogs

Power cord, cap and outlet

G1: G2: G3:

Notes:

Water Quality LM test kit (F.9.000.01)

filtration system manufacturer and type: _____

carbon filter

ion exchange/softener

WAC

reverse osmosis

other/none

value	Min	max	pre	post	value	min	max	pre	post
Total Hardness ppm	5	70			Free Chlorine ppm	0	0.05		
Alkalinity ppm	5	80			Total Chlorine ppm	0	0.1		
Chloride ppm	0	30			pH	6.5	8.5		
Iron ppm	0	0.02			Total Dissolved Solids ppm	10	150		

technician signature: _____

customer Signature: _____