

strada s preventative maintenance 12 month checklist



la marzocco
handmade in florence

Customer: _____

Technician: _____

Date: _____

Machine Data

Serial Number: _____

Voltage: _____

Number of Groups: _____

Replace:

- diffuser screens (F.3.040)
- group gaskets: 8mm (H.3.001) or 8mm silicon (H.3.007)
- steam wand anti-suction valves (L192)
- pressure safety valve (B.2.024)
- steam boiler vacuum breaker (B.2.029)

Check/inspect:

- filter baskets and springs condition
- drain box and hose for leaks or clogs
- all buttons for proper operation
- brewing pressure _____ bar
- expansion valve operation max pressure: _____ bar
- flow meter field resistance (2.2KΩ±10%) G1: _____ kΩ G2: _____ kΩ G3: _____ kΩ
- steam valve operation
- if ABR: run "scale test"
- all fittings and valves for leaks
- flow-rates for each group ml/30s G1: _____ g G2: _____ g G3: _____ g
- Water sensor for leaks water and drain lines
- clean auto-fill probe Power cord, cap and outlet

Notes:

Water Quality LM test kit (F.9.000.01)

filtration system manufacturer and type: _____

	<input type="checkbox"/> carbon filter		<input type="checkbox"/> ion exchange/softener		<input type="checkbox"/> WAC	<input type="checkbox"/> reverse osmosis		<input type="checkbox"/> other/none	
value	Min	max	pre	post	value	min	max	pre	post
Total Hardness ppm	5	70			Free Chlorine ppm	0	0.05		
Alkalinity ppm	5	80			Total Chlorine ppm	0	0.1		
Chloride ppm	0	30			pH	6.5	8.5		
Iron ppm	0	0.02			Total Dissolved Solids ppm	10	150		

technician signature: _____ customer Signature: _____